



REPAIRING YOUR EPDM ONE-PIECE ROOF SYSTEM

Kit Contents

150mm x 250mm Overlay Strip
500ml One Piece Primer
Seam Roller
Scrub Pad
Disposable Gloves

General Information

Wear solvent resistant gloves and goggles when handling adhesives/primers. Read the label on the tins and always open pointing the tin away from the face. Stir the contents for 5 minutes until product is uniform in colour and consistency, unless otherwise stated.

Touch-Push Test: To test for the dryness of an appropriate adhesive push straight down onto the adhesive with a clean dry solvent proof gloved finger. Push forward on the adhesive at an angle. Adhesive should feel tacky but not stringy to the finger.

Instructions

Measure approximately 85mm from either side of tear and mark with chalk. Prime area between chalk lines with primer using the scrub pad as instructed on the tin. Leave to go touch dry, applying the "Touch-Push Test" as above. Carefully lay tape evenly between chalk lines, sticky side down and gradually remove covering film pulling at 90 deg to the tape. Roll the Overlay Strip to fully compress tape to the rubber effecting a watertight seal

£25.00 inc VAT & Carriage